



MoCA Network Adapter

Model # ECB6200

Quick Start Guide

This Quick Start Guide will walk you through the easy steps to connect your MoCA Network Adapter. During this process, we'll show you how to:

A Install the First Adapter

B Install Additional Adapter(s)

Note: Circled numerals correspond to installation step numbers.

©2015 Actiontec Electronics, Inc. Actiontec, Creative Solutions for the Digital Life, and the Actiontec logo are registered trademarks or trademarks of Actiontec Electronics, Inc., in the U.S. or other countries. All other names are properties of their respective owners. Product photo may differ from actual product. However, functionality remains as stated above. Specifications are subject to change without notice.

A Install the First Adapter

Note: See the figure on the back of this guide for more details.

Step 1 Get one **MoCA Network Adapter**.

Step 2 Plug one end of an **Ethernet Cable** into the **Ethernet Port** on the right side of the **Adapter**.

Step 3 Locate your broadband modem/router. Plug the other end of the **Ethernet Cable** into an open **Ethernet Port** on the back of the **Modem/Router**.

Step 4 Locate the **Coaxial Cable** that connects your **HDTV or Set-Top Box** to the nearby **Coaxial Wall Port**. Disconnect the cable at the wall port, and reconnect it to the **TV/STB Out Port** on the left side of the **Adapter**. If no device is connected to the wall port, skip to step 5.

Step 5 Get the **Coaxial Cable** from the Adapter's package. Connect one end of the cable to the **Coax In Port** on the left side of the **Adapter**.

Step 6 Connect the other end of the **Coaxial Cable** to the nearby **Coaxial Wall Port**.

Step 7 Get the Adapter's power adapter. Plug the appropriate end of the **Power Adapter** (External, 5V DC, 2A made by APD, Model #WA-10P05FU) into the **Power Port** on the right side of the **Adapter**, and plug the other end into a **Power Outlet**.

B Install Additional Adapter(s)

If necessary, additional Adapters can be placed in locations around the home/office that need an Ethernet Internet connection, and are near a coaxial port.

To install, follow the instructions in the first section of this quick start guide, "Install the First Adapter," except for step 3. Use the following step 3 instead:

Step 3 Locate the device to connect to the Internet. Plug the other end of the **Ethernet Cable** into an open **Ethernet Port** on the back of the **Device**.

Continue with steps 4 through 7 to complete the installation. Repeat for additional Adapters.

Congratulations! You've successfully connected your device to the Internet. For registration or access to user manuals, wall-mount templates, software updates, etc., go to; <http://www.actiontec.com/339.html>